

KitchenAid®**OVEN PARTS**


For Models: KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07

(Black)

(White)

(Biscuit)

(Stainless Steel)

30" BUILT-IN ELECTRIC
DOUBLE OVEN
THERMAL CONVECTION LOWER
MICROWAVE CONVECTION UPPER

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models:KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07

(Black)

(White)

(Biscuit)

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	9	4452158	Tube, Vent	31	4449809	Screw
	8300653	Installation Instructions	10	4452163	Lens, Light	32	4449743	Screw
	8302973	Use & Care Guide (Oven)	11	4448972	Oven Light Assy	33	9760677	Deflector, Vent
	8302974	Use & Care Guide (Microwave)	12	4452164	Bulb, Light	34	8302592	Vent, Center
	4453330	Cooking Guide (Lable)	13	4452491	Insulation, Grill	35	3400832	Screw
	4452967	Chart, High Speed Cooking	14	9759060	Frame, Front	36	3196176	Screw
	8303852	Tech Sheet (Oven)	15	4455382	Gasket, Door	37	9759243	Thermostat (TOD) (120c) SPST
	4449264	Easy Set Guide	16	4452490	Spacer, Foam	38	4450038	Screw
	3191638	Safer Cooking Tips	17	4452337	Insulation, Bottom Vent	43	9759713	Base, Chassis
	9759133	Safer Cooking Tips	19	4451478	Support, Insulation	49	4448933	Retainer, Gasket
2	4452152	Bracket, Mounting Bottom Trim	20	4451605	Cap, Spacer	50	4451747	Cover, Back
3		Hinge Receiver	21		Rail, Side	51		Trim, Bottom
	4455605	Left Hand		4450583	Right Side		4455443	Black
	4455606	Right Hand		4450584	Left Side		4455445	White
4	4448520	Bumper, Door	22	4449154	Screw		4455447	Biscuit
5		Trim, Side	23	4449040	Screw		4455147	Stainless Steel
		Right Hand	24		Screw		4452152	Bracket, Mounting Bottom Trim
	4455430	Black		8281236	Black	52	4450289	Screw
	4455432	White		694091	S.Steel	53	4451756	Chassis, Back
	4455434	Biscuit	25	4455641	Side, Chassis (R.H. & L.H.)	FOLLOWING PARTS NOT ILLUSTRATED		
	4452083	Stainless Steel Left Hand	26	4452234	Back, Chassis			
	4455431	Black	27		Liner, Oven (Not serviceable)	INSULATION		
	4455433	White	29	4455636	Sensor			
	4455435	Biscuit	30	4449845	Bracket, Support	4449316 Insulation, Wrap 4450365 Insulation, Back		
	4452084	Stainless Steel						
7	4455865	Top Chassis						
8	4452492	Insulation, Top						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS


For Models:KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07

(Black)

(White)

(Biscuit)

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4452604	Panel, Control Black
	4452605	White
	4452974	Biscuit
	4451791	Stainless Steel
2	8302662	Switch, Membrane Black
	8302664	White
	8302668	Biscuit
	8302666	Stainless Steel
3	3400832	Screw
4	4451592	Filter
5	4452260	Spacer, Foam
6	4451632	Bracket, Filter
7	8301991	Assy, Control
8	4449745	Screw
10	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS


For Models: KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07

(Black)

(White)

(Biscuit)

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4457127	Door Liner
2		Hinge, Door
	9760575	R.Side (clear)
	9760576	L.Side (clear)
3	4449259	Glass, Inner
4	4451722	Insulation, Door
5	4457132	Retainer, Glass
6	4449809	Screw
7	9759225	Glass, Inner
8	4449743	Screw
9	3196184	Screw
10	3400832	Screw


Illus. No.	Part No.	DESCRIPTION
12		Door Glass, Assy
	4455391	Black
	4455390	White
	4455395	Biscuit
	4452316	Stainless Steel
13		Door Handle
	4452502	Black
	4452503	White
	4452871	Biscuit
	4455851	Stainless Steel
14		Bracket, Handle
	4455803	Right Hand
	4455804	Left Hand

Illus. No.	Part No.	DESCRIPTION
15	9759229	Bracket(2nd Glass)
16	9759230	Bracket(3rd Glass)
19	4457103	Shield, Heat
21	4452326	Seal, Door Top
22	4457114	Shield, Heat
23		Retainer, Glass-Clip
	4450863	Black
	4450864	White
	4452119	Biscuit
	4451432	Stainless Steel
24	9759228	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LATCH PARTS

For Models: KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent-Top
3	8300791	Bracket, Combo Chassis
4	4449809	Screw
5	4455177	Elbow, Vent-Bottom
6	4451758	Seal, Foam
7	4449040	Screw
8	4450408	Baffle, Rear
9	4449154	Screw
10	9759525	Latch, Motorized
15	4455191	Plate, Blower
16	6610168	Blower
19	4449906	EXT Filler

IMPORTANT PRODUCT SAFETY INFORMATION

ADVISE CONSUMERS OF AN ELECTROCUTION HAZARD WITH DO-IT-YOURSELF REPAIRS OF MICROWAVE OVENS.


The U.S. Consumer Product Safety Commission warns against do-it-yourself repairs of microwave ovens. Microwave ovens use high voltage which makes it particularly hazardous for consumers to remove the cover and touch electrical parts.

STRONGLY RECOMMEND THAT CONSUMERS HAVE PROFESSIONALS REPAIR MICROWAVE OVENS.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4456104	Element, Broil
2	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	4452155	Element, Bake

Illus. No.	Part No.	DESCRIPTION
8	4448881	Nut, Hex
9	4451583	Convection, Motor
10	4452226	Blade, Fan
11	4448882	Washer, Lock
12	4452227	Nut
13	4451355	Jack, Meat Probe
14	4448948	Probe, Meat

Illus. No.	Part No.	DESCRIPTION
15	4455037	Tray, Bake
17	4450039	Cover, Bake Tray
18	4449809	Screw
20	4452157	Element, Convection
21	4448418	Cover, Fan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS


For Models: KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07

(Black)

(White)

(Biscuit)

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models:KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07

(Black)

(White)

(Biscuit)


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4375437	Bracket, Capacitor	32	4375281	Thermostat	54	4375439	Shield, Heat
3	4375252	Rubber Ring	33	4375408	Q Tube Assembly			Right
4	4375038	Screw	34	4375438	Transformer	55	4375422	Sensor, Temp.
5	4375314	Air Duct, Magnetron	35	4375406	Ring, Turntable	56	4375420	Insulation
6	4375253	Support, Tube	36	4375407	Shaft, Turntable	57	4375419	Duct, Heater
7	4375421	Plug, Ceramic	39		Bracket, Hinge	58	4375416	Washer
8	4375255	Bushing		4375412	Left	59	4375417	Element, Heater
9	4375256	Reflector		4375413	Right	60	4375418	Fan
10	4375257	Chamber, Reflector	42	4375331	Plate, Grill	61	4375429	Motor, Fan
12	4375450	Duct, Inlet	43	4375332	Bracket	62		Left-Threaded Nut
13	4375316	Insulation, Switch	44	4375441	Fan Cap			Serviced With
14	4375322	Fan Wheel	46		Switch Holder			Motor Item 61
15	4375317	Duct, Air		4375412	Left	63	4375430	Thermostat
16	4375415	Block, Slide		4375413	Right	64	4375431	Shield, Heat
17	4375248	Cover Plate, Upper	47	4375258	Nut	65	4375432	Insulation
18	4375251	Screw	48		Insulation	66	4375433	Chamber, Heat
19	4375318	Lens, Lamp		4375409	Left Side		Cabinet	
20	4375319	Spring		4375410	Right Side	67	4375437	Isolation Plate
21	4375320	Reflector	49	4375411	Plate, Side	68	4375338	Cover Plate
23	4452220	Rack			Bottom	71		Side Plate
24	4393536	Crisp Plate	50	4375425	Valve		4375341	Left
25	4375436	Capacitor	51	4375428	Screw To Valve		4375342	Right
26	4375424	Magnetron	52	4375427	Thermoactuator	72	4455919	Turntable
27	4375321	Fuse	53	4375426	Air Bleed	73	4375346	Switch
28	4375231	Block, Fuse				74	4375278	Motor, Turntable
29	4375278	Motor, Blower				75	4375348	Lamp
30	4375279	Thermostat				76	4375349	Rectifier
31	4375423	Thermostat						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE COMPARTMENT PARTS

For Models: KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
5	4452551	Support Rails Right Side
	4452552	Left Side
6	4449809	Screw
11	4452548	Rear Channel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS


For Models:KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07

(Black)

(White)

(Biscuit)

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4450378	Cover, Top
2	4448935	Baffle, Blower
3	4452003	Blower (45MM)
	4450920	Blower (1200RPM)
4	4451789	Plate, Mounting
5	4452104	Transformer, (Lights) (2)
6	4451634	Exhaust Duct
7	4450027	Bracket, Duct
8	4449964	Grommet
9	4454949	Holder, Fuse
10	4454976	Fuse

Illus. No.	Part No.	DESCRIPTION
11	4449868	Block, Terminal
12	4452559	Side, Combo
13	4456145	Vent, Control Panel
14		Side, Control Top
	4451597	Right
	4451598	Left
15	4452244	Back, Control
16	4450551	Cover, Top Rear
17	4448664	Clamp
18	4452367	Cover, Top Front

Illus. No.	Part No.	DESCRIPTION
19	4455038	Transformer, Control
20	4452247	Cover, Plate
21	4451934	Suppressor
22	9752759	Relay, Double Line Break
23	3400832	Screw
24	4449809	Screw
25	4449154	Screw
26	3400080	Screw
27	4450038	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE DOOR PARTS


For Models:KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07

(Black)

(White)

(Biscuit)

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4448937	Glass, Middle
2	8303556	Frame, Door
3	4450038	Screw
4		Bracket, Mounting
	4449141	Right Side
	4449142	Left Side
5		Filler, Side
	4449083	Right Side
	4449086	Left Side
6		Handle, Door
	4452502	Black
	4452503	White
	4452871	Biscuit
	4455851	Stainless Steel

Illus. No.	Part No.	DESCRIPTION
7		Glass, Outer
	4452211	Black
	4452789	White
	4452995	Biscuit
	4452259	Stainless Steel
8	4449809	Screw
9	4452331	Bracket, Handle
10		Retainer, Glass-Clip
	4450863	Black
	4450864	White
	4452119	Biscuit
	4451432	S.Steel
11	4375339	Door, Plate
12	4375414	Frame, Inner

Illus. No.	Part No.	DESCRIPTION
13	4375330	Strap, Door
14	4375313	Screw
15		Hinge, Door
	4375323	Left
	4375324	Right
16	4451009	Sprng,Trsn (RH)
	4452398	S.Steel (RH)
17	3196184	Screw
18	4452395	Sprng,Trsn(LH)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:KEHC309JBL07, KEHC309JWH07, KEHC309JBT07, KEHC309JSS07

(Black)

(White)

(Biscuit)

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black

PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

SPLICING WIRES--25FT.

LENGTH

	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

WIRING HARNESS PARTS

	8301909	Harness, Latch
	4449809	Screw
	8301923	Harness, Main
	4450831	Ground (M/W)
	4450800	Screw, Ground
	8303838	Harness, Main Filter
	4449809	Screw
	4450950	Conduit, Combo
	313438	Clip, Harness
	4452222	Spacer, Harness
	4454835	Tie, Cable
	4452400	Lead, Ground

Miscellaneous

	4448950	Screw, Install (4)
	814381	Hinge Pin Kit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST